


3856330



785-810



Installation manual

2 D019*1	3 6mm 308GA-6*1	4 8mm 308GA-8*1	5 D018*1	1 X1
6 D017*1	7 S018*1	8 *9	9 *3	
10 *5	11 *3	12 M28*1	13 DS011-5L/R*1	
14 DS012L/R*1	15 DS010-3*1	16 *5	3856330 packing	

Tools for installation



A



B



C



D



E



F









G









H

Step 1:




②

Step 2:




③


Step 3:





④





Step 4:



⑤



Step 5:



B

C

D



E

F

H

